

# Slack Redistribution for Graceful Degradation Under Voltage Overscaling

Andrew B. Kahng<sup>††</sup>, Seokhyeong Kang<sup>†</sup>, Rakesh Kumar<sup>‡</sup> and John Sartori<sup>‡</sup>

<sup>†</sup>ECE and <sup>††</sup>CSE Departments, University of California at San Diego

<sup>‡</sup>Coordinated Science Laboratory, University of Illinois

abk@cs.ucsd.edu, shkang@vlsicad.ucsd.edu, rakeshk@illinois.edu, sartori2@illinois.edu

**Abstract**—Modern digital IC designs have a *critical operating point*, or “wall of slack”, that limits voltage scaling. Even with an error-tolerance mechanism, scaling voltage below a critical voltage - so-called *overscaling* - results in more timing errors than can be effectively detected or corrected. This limits the effectiveness of voltage scaling in trading off system reliability and power. We propose a design-level approach to trading off reliability and voltage (power) in, e.g., microprocessor designs. We increase the range of voltage values at which the (timing) error rate is acceptable; we achieve this through techniques for *power-aware slack redistribution* that shift the timing slack of frequently-exercised, near-critical timing paths in a power- and area-efficient manner. The resulting designs heuristically minimize the voltage at which the maximum allowable error rate is encountered, thus minimizing power consumption for a prescribed maximum error rate and allowing the design to fail more gracefully. Compared with baseline designs, we achieve a maximum of 32.8% and an average of 12.5% power reduction at an error rate of 2%. The area overhead of our techniques, as evaluated through physical implementation (synthesis, placement and routing), is no more than 2.7%.

## I. INTRODUCTION

The traditional goal of IC design is for the product to always operate correctly, even under worst-case combinations of (process, voltage, temperature, wear-out, etc.) non-idealities. It is well-recognized that designing for worst-case operating conditions incurs considerable area, power and performance overheads [5], and that these overheads worsen with increased manufacturing or runtime variations in advanced technology nodes [24]. *Better-than-worst-case* (BTWC) design [1] allows reliability (in the sense of timing and hence functional correctness) to be traded off against performance and power. The central idea, as exemplified by the shadow-latch technique in *Razor* [5], is to design for average-case conditions (thus saving area and power) while adding an error detection and correction mechanism to handle errors that occur with worst-case variabilities. System-level techniques, as exemplified by *Algorithmic Noise Tolerance* [13], allow timing errors to proliferate into the system or application, but then exploit algorithmic and/or cognitive noise tolerance in mitigating errors at the application level. The use of such application- or system-level error detection and correction is assumed in proposed probabilistic SOC [3] and stochastic processor architectures [18], which are recent classes of BTWC designs.

Our work focuses on the *optimized* application of voltage overscaling for power reduction in the context of BTWC design. Figure 1 illustrates power consumption under voltage scaling in BTWC designs. In the left plot, functional errors begin to occur below the voltage  $v_b$ , but we can reduce power consumption until we reach the voltage  $v_c$ , given the use of error correction. The right plot shows that below the voltage  $v_c$ , power consumption is increased because of recovery overhead.

The impact of BTWC design techniques is often limited in high-performance digital designs by a *critical operating point* or “wall of slack” phenomenon that limits voltage overscaling and, more importantly, is a direct consequence of today’s standard approach to power optimization. The Critical Operating Point (COP) hypothesis [19] (cf. Figure 1(a)), in the context of voltage scaling, states that a




Fig. 1. Error rate (a) and power consumption (b) versus voltage scaling in BTWC designs.

modern digital design will have a critical operating voltage  $V_c$  above which zero timing errors occur, and below which massive timing errors occur. The COP hypothesis is natural in light of how modern designs are optimized for power and area, subject to a frequency constraint: negative timing slack (on a combinational path) is cured by upsizing and buffering, while positive timing slack is traded off for area and power reductions. Thus, in the final design, many timing paths are critical, and there is a “wall of (critical) slack”. The COP hypothesis states that overscaling beyond the critical voltage can abruptly cause error rates beyond what an error-tolerance mechanism can handle. According to [19], this has been confirmed in general-purpose microprocessors. A key motivation for our work is that COP behavior limits the applicability of voltage scaling in trading off reliability for power - even in the context of BTWC design.

Our work seeks to improve the effectiveness of BTWC design techniques through *power-aware slack redistribution*, a novel design approach that enables extended voltage-reliability tradeoffs. Power-aware slack redistribution reapportions timing slack of frequently occurring, near-critical timing paths to increase the level of overscaling (i.e., reduce the minimum voltage) at which a given error-tolerance mechanism can maintain an acceptable timing error rate. The result is a design that fails more gracefully, and achieves significantly improved power savings with only small degradation of application performance.

In the following, Section II reviews previous work, and Section III formalizes the problem of achieving “gradual slope” in the timing slack distribution, and hence graceful degradation of correctness with voltage overscaling. Section IV describes our power-aware slack redistribution techniques, and Section V discusses implementation and experimental methodology. Section VI presents results and analysis, and Section VII concludes.

## II. RELATED WORK

### A. BTWC Designs

Better-than-worst-case (BTWC) design approaches allow circuits to save power by optimizing for normal operating conditions rather than worst-case conditions. One class of BTWC techniques allows adaptation to runtime conditions by specifying multiple safe voltage and frequency levels at which a design may operate, and allows for

switching between these states. Examples in this class are Correlating VCO [2], [12] and *Design-Time DVS* [23]. Another class of BTWC designs uses “canary” circuits, including delay-line speed detectors [4] and triple-latch monitors [16], to detect when critical timing (failure) is imminent and thus avoid any unsafe voltage scaling. Finally, *Razor* [5] and *ANT* techniques [13] provide error tolerance at the circuit- and algorithm-level, respectively. Their benefits under voltage scaling are limited not only by COP behavior but by the overhead of error correction that is increasingly required as voltage is scaled.

### B. Design-level Optimizations

Design-level optimizations for timing speculation architectures ([8], [20], [7]) identify and optimize frequently-exercised timing paths, while other (infrequently-exercised) paths are allowed to have timing errors. *EVAL* [20] trades error rate for processor frequency by using system-level configurations to shift or otherwise reshape path delay distributions of various functional units. *BlueShift* [8] is an application of *EVAL* that identifies most frequently violated timing constraints and optimizes the corresponding timing paths using forward body biasing and path constraint tuning (PCT) (essentially, setup timing over-constraints). *CRISTA* [7] also addresses variation-tolerant circuit design by using *Shannon expansion-based* partitioning to isolate critical paths. Critical paths with low activity are separated and de-optimized.

### C. Cell Sizing

Many previous works use cell sizing for power or area recovery subject to timing constraints. Generally, positive (setup) timing slack on non-timing critical cell instances can be flexibly ‘traded’ for power and area objectives (gate-length increase or  $V_{th}$  swap to reduce leakage, or gate-width decrease to reduce area and total power). Fishburn and Dunlop propose a fast iterative method to meet delay constraints called *TILOS* [6]. *TILOS* uses the Elmore delay model for transistor delays, and proposes a heuristic that sizes transistors iteratively, according to the sensitivity of the critical path delay to the transistor sizes, i.e., finding a greedy (maximum delay reduction / transistor width increase) “move” at each iteration. The method of *Duet* [21] performs simultaneous assignment of threshold voltage ( $V_{th}$ ) and transistor width using a merit (sensitivity) function. Gupta et al. propose small biases of transistor gate length to further minimize leakage power [10]. They also present a sensitivity-based downsizing approach for transistor-level  $V_{th}$  assignment [9], and a post-layout, post-signoff gate length biasing technique for parametric yield (leakage and leakage variability) optimization [11]. Jeong et al. revisit a general linear programming (LP) formulation that can concurrently exploit multiple knobs ranging from multi- $L_{gate}$  footprint-compatible libraries to post-layout  $L_{gate}$  biasing [14].

Our work, detailed below, uses post-layout cell resizing to redistribute timing slack so as to achieve a switching activity-aware ‘gradual slope’ distribution of timing slack. We believe that ours is the first to do so specifically in the BTWC context; moreover, our proposed methodology can find frequently exercised paths rapidly (without repeated gate-level simulation as in *BlueShift*).

## III. THE GOAL OF DESIGN OPTIMIZATION

We minimize power consumption for a given error rate by minimizing the voltage at which that error rate can still be observed. Traditional designs exhibit a critical wall of slack in which the path slacks for the majority of paths are similar and close to the critical path slack of the circuit (observe the red curve in Figure 2).

For traditional designs, our goal of aggressively reducing the operating voltage to save power is thwarted by the critical wall of slack, because scaling past the wall results in a catastrophic number of timing violations. To alleviate this restraint, we seek to reshape

the slack distribution of a circuit to have a gradual slope rather than the steep slope that characterizes the critical wall (observe the blue curve in Figure 2).




Fig. 2. The goal of the ‘gradual slope’ slack optimization is to transform a slack distribution having a critical ‘wall’ into one with a more gradual failure characteristic.

To achieve the desired slack distribution that permits aggressive voltage scaling, we must alter the slack of some paths to break down the critical wall. In our optimization approach, we increase the slack of frequently executed critical paths to reduce the onset of errors when voltage is scaled. Likewise, we can reduce the slack of rarely exercised paths, since these paths will not have a significant impact on error rate when voltage is scaled. Together, these path slack adjustments will reshape the slack distribution of a circuit and extend the range of voltage scaling. The goals of our optimization are expressed in Figure 2.

## IV. SLACK REDISTRIBUTION AND POWER REDUCTION

We now present our cell swapping approach to achieve a gradual, activity- (and hence power-) aware timing slack distribution for a given circuit design.

### A. Power-aware Slack Redistribution Using Cell Swap Method

Our slack distribution optimizer is implemented in C++ and performs cell swapping (gate sizing only, with no logic resynthesis) using the *Synopsys PrimeTime vB-2008.12-SP2* [27] tool and its built-in *Tcl* socket interface. Traditional optimization tools treat all paths equally: all negative-slack paths must be brought up to zero or positive slack. By contrast, to improve the performance-power profile of the design, we spend our optimization efforts on frequently-exercised paths in order to minimize error rates under voltage overscaling.

Our heuristic determines a target voltage corresponding to a specific error rate, and then ‘over-optimizes’ frequently-exercised paths using upsizing (i.e., increase of transistor width and hence drive strength) cell swaps. Figure 3 illustrates the challenges inherent in setting the target voltage. The figure shows path delay changes after slack optimization for a fixed target voltage, where the optimizer swaps cells in *Paths A, B* and *C* to reduce the slack of those paths with respect to the fixed target voltage. However, if the voltage at which the maximum acceptable error rate is observed is larger than the target voltage as specified by the red-dotted line, *Paths A* and *C* are optimized unnecessarily beyond the actual scaled voltage, and power is wasted.

Our slack optimization approach finds a target voltage after estimating error rates at each operating voltage, and iteratively optimizes paths while scaling voltage. At the initially selected voltage, the optimizer performs cell swaps to improve timing slack. After performing this timing optimization at the initially selected voltage, the voltage is scaled until the target error rate is reached. Figure 4 illustrates the optimization heuristic. *Path A* is optimized until the target voltage is reached, but *Path C* is not optimized, since *Path C* does not have negative slack at the target voltage.




Fig. 3. Path delay before and after slack optimization with a fixed target voltage.




Fig. 4. Target voltage and path slack before and after slack optimization using the heuristic.

To enable proper voltage selection, we must accurately forecast error rates without resorting to time-consuming functional simulation. Accurate error rate estimation ensures that we do not over-optimize, resulting in too much area overhead, or under-optimize, thus limiting the possible extent of voltage scaling. For this purpose, we use toggle information of flip-flops that have negative timing slack. The toggle information consists of toggles from both negative-slack paths and positive-slack paths; in the error rate calculation, only toggles from negative-slack paths are considered. Hence, the error rate in a single flip-flop,  $ER_{ff}$ , can be estimated by Equation (1).

$$ER_{ff} = TG_{ff} \times \frac{\sum TG_{p\_neg}}{\sum TG_{p\_all}} \quad (1)$$

In Equation (1),  $TG_{ff}$  is the toggle rate of flip-flop  $ff$ ,  $TG_{p\_neg}$  and  $TG_{p\_all}$  are the toggle rates of a negative slack path  $p\_neg$  and all paths  $p\_all$  to flip-flop  $ff$ . We obtain an aggregate error rate as the summation of error rates in all flip-flops. However, this value will be significantly larger than the actual error rate observed during functional simulation, it does not account for errors that occur in the same clock cycle. Moreover, the existence of false paths also imparts pessimism to the estimated error rate. We therefore use a parameter  $\alpha$ , obtained from experimental investigations, to compensate for this pessimism. The estimated error rate of a target design  $D$  is defined in Equation (2), with the compensation parameter  $\alpha$ . In the experiments reported below, a value of  $\alpha = 0.5$  is used.

$$ER_D = \alpha \times \sum_{ff \in D} ER_{ff} \quad (2)$$

Figure 6 compares estimated error rates and actual error rates at each operating voltage. The estimated error behavior roughly matches the actual error behavior, and we can find an appropriate target voltage based on the estimated error rate.

After finding a target voltage, the *slack optimizer* finds negative-slack paths by tracing backward from flip-flop cells using a depth-first search (DFS) algorithm. We optimize by swapping (i.e., resizing) cells with other library cells that have identical functionality. We determine priority according to the switching activity of a path, defined as the minimum toggle rate over all cells in the path. Cell swapping is performed on all cells in a given target path, and only swaps that improve timing slack of the path are accepted.<sup>1</sup> There is significant order-dependence - and hence impact of prioritization

<sup>1</sup>We consider only setup timing slack, since hold violations can typically be fixed by inserting hold buffers in a later step.

- since we do not allow the optimizer to touch a previously-swapped cell; the intuition here is that this helps avoid 'cycling' of configurations and also reduces runtime. After cell swapping, the optimizer checks the timing of fan-in and fan-out cells that have been previously touched. When there is no timing degradation in the connected neighboring cells, the cell change is finally accepted.

#### Algorithm 1 Pseudocode for the *slack optimizer*.

##### Procedure *SlackOptimizer*( )

```

1. Read netlist and initialize PrimeTime Tcl socket interface;
2. Read switching activity (toggle rate) of each cell;
3. //Scale and find target voltage
4. for  $V_{target} = 1.00V$  to  $0.50V$ ;  $V_{target} \leftarrow V_{target} - 0.01V$  do
5.   Load Library (.lib) for the target voltage  $V_{target}$ ;
6.    $ER \leftarrow ComputeErrorRate(V_{target})$ ;
7.   if  $ER > ER_{target}$  then
8.      $P \leftarrow FindCriticalPaths()$ ;
9.      $OptimizePaths(P)$ ;
10.  else
11.    continue
12.  end if
13. //Terminate algorithm after checking error rate and power
14.  $ER \leftarrow ComputeErrorRate(V_{target})$ ;
15.  $PWR \leftarrow ReportTotalPower(V_{target})$ ;
16. if  $PWR > PWR_{prev}$  then
17.    $RestoreSwaps()$ ; break;
18. else if  $ER > ER_{target}$  then
19.   break;
20. else
21.    $PWR_{prev} \leftarrow PWR$ ; continue;
22. end if
23. end for
24. Save list of swaps and perform ECO with SOCE;
```

##### Procedure *OptimizePaths*( $P$ )

```

1. while  $P \neq \emptyset$  do
2.   Pick the critical path  $p$  with maximum switching activity;
3.    $P \leftarrow P - p$ ;
4.   while swap count is not zero do
5.     for  $i = 0$  to  $|p|$  do
6.       if  $flag_{c(i)}$  then
7.         continue;
8.       end if
9.       for all alternative LibCell for the cell instance  $c(i)$  do
10.        Resize the instance  $c(i)$  with LibCell;
11.        Check the path slack of  $p$ ;
12.        for all fanin and fanout cell  $c_{fan}$  of  $c(i)$  do
13.          if  $flag_{c_{fan}}$  then
14.            Check the slack of critical path  $p_{fan}$  of  $c_{fan}$ ;
15.          end if
16.        end for
17.        if  $\Delta slack(p) < 0$  or  $\Delta slack(p_{fan}) < 0$  then
18.          Restore cell change;
19.        end if
20.         $flag_{c(i)} \leftarrow true$ ;
21.      end for
22.    end for
23.  end while
24. end while
```

Algorithm 1 presents pseudocode of the optimizer.  $ComputeErrorRate(V_{target})$  estimates error rates, as defined by Equation (2).  $ER_{target}$  is a target error rate, which can be set to the maximum allowable error rate. The  $FindCriticalPaths()$  function finds all negative-slack paths in the design, and  $ReportTotalPower(V_{target})$  reports the total power consumption from *Synopsys PrimeTime*. In the pseudocode, the target voltage is iteratively scaled by an additional 0.01V until the error rate exceeds a target error rate. Then, the heuristic optimizes critical paths at the target voltage. If the power consumption is not reduced after the voltage scaling, the latest swaps are restored by the  $RestoreSwaps()$  function and the optimization is terminated.

**Algorithm 2** Pseudocode for the *power reduction*.

---

```

Procedure PowerReduction( )
1. SlackOptimizer( );
2. Insert all cells into set C;
3. while C ≠ ∅ do
4.   Pick the cell c and check the cell slack  $d_c$  and toggle rate  $Tg_c$ ;
5.   if  $d_c > 0$  or  $Tg_c < \beta$  then
6.     for all alternative LibCell for the cell instance  $c(i)$  do
7.       Resize the instance  $c(i)$  with LibCell;
8.       Check the total power  $pw$  of the cell  $c$ ;
9.       for all fanin and fanout cell  $c_{fan}$  of  $c(i)$  do
10.        if  $\Delta slack(c_{fan}) < 0$  and  $Tg_{c_{fan}} > \gamma$  then
11.          Restore cell change;
12.        else if  $pw_{c(i)} > pw_{c(i-1)}$  then
13.          Restore cell change;
14.        end if
15.      end for
16.    end for
17.  end if
18.  C ← C − c;
19. end while
20. Save list of swaps and perform ECO with SOCE;

```

---

**B. Power-aware Post-processing**

In addition to the above slack optimization, we can also reduce power consumption by downsizing cells on rarely-exercised paths. Algorithm 2 shows this post-processing heuristic. The *power reduction* procedure downsizes cells logical equivalents with smaller power consumption. Two parameters govern cell selection and swap acceptance. First, a cell is selected that has positive slack or is in a rarely-exercised path. The cell's toggle rate should be less than  $\beta$ , where the parameter  $\beta$  is set small enough for us to expect an insignificant effect on error rate. Downsizing cell swaps are accepted as long as they do not increase error rate; to this end, a second variable  $\gamma$  characterizes the cell's effect on neighboring cells. If the timing slack of the neighboring cells which have larger toggle rate than  $\gamma$ , the downsizing is restored. Within these constraints, the optimizer selects the best candidate cells to reduce power without affecting error rate.

**V. METHODOLOGY**

Figure 5 illustrates our overall flow for gradual-slope slack optimization. The *switching activity interchange format* (SAIF) file provides toggling frequency for each net and cell in the gate-level netlist; it is derived from a value change dump (VCD) file from gate-level simulation using in-built functionality of the *Synopsys PrimeTime-Px* [27] tool. To find timing slack and power values at the specific voltages, we prepare *Synopsys Liberty* (.lib) files for each voltage value – from 1.00V to 0.50V in 0.01V increments – using *Cadence SignalStorm TSI61* [28].




Fig. 5. CAD flow incorporating our *slack optimizer* to create a design with gradual-slope slack distribution.

We use the *OpenSPARC T1* processor [25] to test our optimization framework. Table I describes the selected modules and provides characterization in terms of cell count and area.

TABLE I  
TARGET MODULES FOR EXPERIMENTS.

Module	Stage	Description	Cell #	Area (um <sup>2</sup> )
lsu_dctl	MEM	L1 Dcache Control	4537	13850
lsu_qctl1	MEM	LDST Queue Control	2485	7964
lsu_stb_ctl	MEM	ST Buffer Control	854	2453
sparc_exu_div	EX	Integer Division	4809	14189
sparc_exu_ecl	EX	Execution Unit Control Logic	2302	7089
sparc_ifu_dec	FD	Instruction Decode	802	1737
sparc_ifu_errdp	FD	Error Datapath	4184	12972
sparc_ifu_fcl	FD	L1 Icache and PC Control	2431	6457
spu_ctl	SPU	Stream Processing Control	3341	9853
tlu_mmu_ctl	MEM	MMU Control	1701	5113

Gate-level simulation is performed using test vectors obtained from full-system RTL simulation of a benchmark suite consisting of bzip2, equake and a sorting test program. These benchmarks are each fast-forwarded by 1 billion instructions using the OpenSPARC T1 system simulator, Simics [17] Niagara. After fast-forwarding in Simics, the architectural state is transferred to the *OpenSPARC* RTL using *CMU Transplant* [22]. More details of our architecture-level methodology are available in [15].

Switching activity data gathered from gate-level simulation is fed to *Synopsys PrimeTime (PT)* static timing tool through its *Tcl* socket interface. Timing slack and switching activity information is continually available from *PT*, through the *Tcl* socket interface, during the optimization process. After our optimization, all netlist changes are realized using *Cadence SoC Encounter v7.1* [29] in ECO (engineering change order) mode.

Module designs are implemented in TSMC 65GP technology using a standard flow of synthesis with *Synopsys Design Compiler vY-2006.06-SP5* [26] and place-and-route with *Cadence SoC Encounter*. As noted above, voltage scaling effects are captured by characterizing *Synopsys Liberty* libraries (using *Cadence SignalStorm TSI61*) at a number of operating voltages. Runtime is reduced by adopting a restricted library of 63 commonly-used cells (62 combinational and 1 sequential); the total characterization time for 51 voltage points is around two days, but this is a one-time cost.

Using our *slack optimizer*, we optimize the module implementations listed in Table I, and then estimate error rates by counting cycles with timing failures during gate-level simulation. We use a SCAN-like test wherein the test vectors specify the value of each primary input and internal flip-flop at each cycle. This prevents pessimistic error rates due to erroneous signals propagating to other registers. We emulate the SCAN test by connecting all register output ports to the primary input ports, allowing full control of module state.

**VI. RESULTS AND ANALYSIS**

Our experimental results compare the performance of our slack optimization flow against several alternatives for 10 component modules of the *OpenSPARC T1* processor [25]. In addition to traditional CAD flows targeting loose (0.8GHz) and tight (1.2GHz) timing constraints we also compare against an implementation of *BlueShift* [8] that optimizes paths in decreasing order of the product of negative slack (magnitude) and switching activity. When voltage is scaled, such paths cause the most timing violations, and we reduce errors by assigning tighter timing constraints during P&R with *Cadence SoC Encounter*. We perform gate-level simulation of modules to estimate error rates and power consumption at different voltages. For all experiments, we use a compensation factor of  $\alpha = 0.5$  (Equation (2)), and set  $\beta = \gamma = 10^{-4}$  in Algorithm 2.

Table II demonstrates the impact of slack optimization in reducing power consumption for our test modules. Benefits estimated at




Fig. 6. Actual error rates vs. estimated error rates for various modules in Table I.

optimization time are compared to actual simulated results, showing the power reduction afforded for an error rate of 2%. Discrepancies between the actual and estimated results are primarily due to the inaccuracy of the error rate estimation technique. The slack optimizer achieves up to 25.8% power reduction by redistributing slack and extending the range of voltage scaling. The power reduction stage provides additional benefits, up to 3.6%, by downsizing cells on infrequently exercised paths.

We note that not all modules achieve substantial benefits. Power reduction from baseline is limited for *sparc\_exu\_div*, *sparc\_ifu\_errdp* and *tlm\_mmu\_ctl*. These modules have low switching activity, and their error rates remain below 2% even for when voltage is scaled down to 0.5V. Consequently, both the baseline and slack-optimized implementations achieve the same benefits for these modules. Significant benefits can be achieved when the original slack distribution of the module dictates that errors increase rapidly. In that case, the slack optimizer is able to redistribute slack and extend the range of voltage scaling.

Figure 7 shows how error rate varies as voltage is scaled for each of the *OpenSPARC T1* modules. The slack optimizer redistributes timing slack so that the error rate for a module increases more gradually as voltage is scaled down. Aggressive optimization can in some cases result in a lower error rate for tightly constrained P&R or BlueShift, but our goal is ultimately not to reduce error rate but rather to reduce power consumption.

Figure 8 shows the power consumption of the modules at each operating voltage, demonstrating that although aggressive optimization can result in a lower error rate, this comes at considerable power expense due to increased area from cell upsizing. The area overhead of the slack optimizer is significantly lower than with the other approaches, since it targets the specific cells for which upsizing produces the most benefit. The additional power reduction stage even reclaims some of this area overhead, reducing power almost to that of the baseline at the same voltage. Table III shows the average area overhead of each design approach.

TABLE III  
AREA OVERHEAD OF DESIGN APPROACHES.

Tight P&R	BlueShift	Slack Optimizer	SlackOpt + PowerReduce
20.3%	6.5%	2.7%	2.7%

The slack optimizer maximizes the benefits gained per each increase area cost. This efficient slack redistribution approach results in lower power for a given error rate, as shown in Figure 9. Benefits are chiefly due to the ability to scale voltage to a lower level for the same error rate. Even though aggressive approaches can sometimes increase the range of voltage scaling further than the slack optimizer, the power overhead of these approaches outweighs the power savings of voltage scaling, and total power is even higher than that of the baseline in many cases. Power-aware slack redistribution, on the other hand, does well to reduce power consumption at the target error rates

for the diverse set of modules, in spite of its slight area overhead (2.7%).

Figure 10 shows the slack distribution of each design technique – traditional SP&R (tightly constrained), *BlueShift PCT*, and *slack optimizer* for *lsu\_dctl*. We note that power-aware slack redistribution results in a more gradual slack distribution. Thus, the slack-optimized design will have fewer failing paths as voltage is scaled down. Figure 11 compares the slack distribution for all modules before and after slack optimization. For some modules (*tlm\_mmu\_ctl*, *sparc\_ifu\_errdp*), the slack distribution is relatively unchanged after slack optimization (again, because the error rates of these modules are low), and optimization is not performed unless an error rate of 2% is exceeded. For *sparc\_exu\_div*, the slack distribution remains unchanged because the optimization heuristic is unable to reduce the delay on critical paths through cell swapping.




Fig. 10. Slack distribution of each design technique (target module : *lsu\_dctl*).

## VII. SUMMARY AND CONCLUSION

Our work enables an extended power-reliability tradeoff in digital designs by optimizing the slack distribution for ‘gradual-slope’ in a toggle rate-aware manner. Our *power-aware slack redistribution* lowers the minimum voltage with acceptable timing error rate, and leads to designs that not only can be run with lower power, but that also fail more gracefully. We demonstrate the impacts of ‘gradual-slope’ design on voltage overscaling and total system power, using modules from the *OpenSPARC T1* benchmark and 65nm SP&R implementation. Our experiments show a maximum of 32.8% and an average of 12.5% total power savings over the baseline design at an error rate of 2% (cf. Table II). The area overhead of our technique is no more than 2.7%.

Our ongoing research seeks CAD techniques for similar extended reliability-power tradeoffs for embedded memories, as well as the exploitation of heterogeneity in multi-core architectures to reduce average-case overhead of our gradual-slack optimization (with heterogeneously reliable and gracefully-degrading cores). Additionally, our present techniques can be augmented to consider metrics of ‘architecture-level criticality’ in addition to path timing slack, so as to further reduce overhead of increased resilience and more graceful system degradation with voltage overscaling.






Fig. 7. The response of error rate to voltage overscaling for each of the *OpenSPARC T1* modules.




Fig. 8. Power consumption at each operating voltage of the *OpenSPARC T1* modules.




Fig. 9. Power consumption at each target error rate of the *OpenSPARC T1* modules.

TABLE II  
EXPERIMENTAL RESULTS - POWER REDUCTION AFTER OPTIMIZATION

Design	Estimated results (slack optimizer)					Actual results (after ECO and simulation)							
	Before optimization		After optimization			Before optimization		After <i>slack optimizer</i>			After <i>power reduction</i>		
	Voltage (V)	Power (W)	Voltage (V)	Power (W)	Reduction (%)	Voltage (V)	Power (W)	Voltage (V)	Power (W)	Reduction (%)	Voltage (V)	Power (W)	Reduction (%)
lsu_dctl	0.92	4.25E-4	0.74	2.70E-4	36.39	0.76	3.10E-4	0.66	2.41E-4	22.26	0.66	2.30E-4	25.81
lsu_qctl1	1.00	2.96E-4	0.85	2.07E-4	30.24	0.86	2.36E-4	0.82	2.14E-4	9.32	0.82	2.11E-4	10.59
lsu_stb_ctl	0.96	8.11E-5	0.92	7.55E-5	7.00	0.71	4.61E-5	0.66	4.04E-5	12.36	0.66	3.99E-5	13.45
sparc_exu_div	0.84	3.04E-4	0.84	3.04E-4	0.00	0.5	1.06E-4	0.5	1.06E-4	0.00	0.5	1.05E-4	0.94
sparc_exu_ecl	0.88	1.99E-4	0.73	1.43E-4	28.53	0.91	2.41E-4	0.74	1.63E-4	32.37	0.74	1.62E-4	32.78
sparc_ifu_dec	1.00	5.73E-5	0.81	3.98E-5	30.55	0.66	2.46E-5	0.63	2.38E-5	3.25	0.63	2.37E-5	3.66
sparc_ifu_errdp	0.56	1.22E-4	0.55	1.17E-4	3.78	0.51	1.11E-4	0.51	1.12E-4	-0.90	0.51	1.10E-4	0.90
sparc_ifu_fcl	0.98	2.21E-4	0.85	1.69E-4	23.34	0.85	1.77E-4	0.74	1.38E-4	22.03	0.74	1.35E-4	23.73
spu_ctl	0.69	1.43E-4	0.65	1.26E-4	11.75	0.59	1.13E-4	0.56	1.02E-4	9.73	0.56	9.99E-5	11.59
tlu_mmu_ctl	0.74	9.60E-5	0.73	9.37E-5	2.35	0.5	4.62E-5	0.5	4.62E-5	0.00	0.5	4.56E-5	1.30




Fig. 11. Slack distribution of various modules in Table I (before and after slack optimization)

## VIII. ACKNOWLEDGMENTS

Work at UIUC was supported in part by Intel, NSF, GSRC, and an Arnold O. Beckman Research Award. Work at UCSD was supported in part by MARCO GSRC and the National Science Foundation. Feedback from Janak Patel, Steve Lumetta, Sanjay Patel, Naresh Shanbhag, and anonymous reviewers helped improve this paper.

## REFERENCES

- [1] T. Austin, V. Bertacco, D. Blaauw and T. Mudge, "Opportunities and Challenges for Better Than Worst-Case Design", *Proc. Asia and South Pacific Design Automation Conf.*, 2005, pp. 2-7.
- [2] T. D. Burd, S. Member, T. A. Pering, A. J. Stratakos and R. W. Brodersen, "A Dynamic Voltage Scaled Microprocessor System", *IEEE Journal of Solid-State Circuits*, 35(11), 2000, pp. 1571-1580.
- [3] L. N. Chakrapani, B. E. S. Akgul, S. Cheemalavagu, P. Korkmaz, K. V. Palem and B. Seshasayee, "Ultra-Efficient (Embedded) SOC Architectures Based on Probabilistic CMOS (PCMOS) Technology", *Proc. Design Automation and Test in Europe*, 2006, pp. 1110-1115.
- [4] S. Dhar, D. Maksimović and B. Kranten, "Closed-Loop Adaptive Voltage Scaling Controller for Standard-Cell ASICs", *IEEE/ACM Proc. International Symposium on Low Power Electronics and Design*, 2002, pp.103-107.
- [5] D. Ernst, N. S. Kim, S. Das, S. Pant, R. Rao, T. Pham, C. Ziesler, D. Blaauw, T. Austin, K. Flautner and T. Mudge, "Razor: A Low-Power Pipeline Based on Circuit-Level Timing Speculation", *IEEE/ACM Proc. International Symposium on Microarchitecture*, 2003, pp. 7-18.
- [6] J. P. Fishburn and A. E. Dunlop, "Tilos: A Polynomial Programming Approach to Transistor Sizing", *Proc. ACM/IEEE International Conference on Computer-Aided Design*, 1985, pp. 326-328.
- [7] S. Ghosh and K. Roy, "CRISTA: A new paradigm for low-power and robust circuit synthesis under parameter variations using critical path isolation", *TCAD*, November 2007.
- [8] B. Greskamp, L. Wan, W. R. Karpuzcu, J. J. Cook, J. Torrellas, D. Chen and C. Zilles, "BlueShift: Designing Processors for Timing Speculation from the Ground Up", *IEEE International Symposium on High Performance Computer Architecture*, 2009, pp. 213-224.
- [9] P. Gupta, A. B. Kahng and P. Sharma, "A Practical Transistor-Level Dual Threshold Voltage Assignment Methodology", *Proc. of International Symposium on Quality Electronic Design*, 2005, pp. 421-426.
- [10] P. Gupta, A. B. Kahng, P. Sharma and D. Sylvester, "Selective Gate-Length Biasing for Cost-Effective Runtime Leakage Control", *IEEE/ACM Proc. of Design Automation Conference*, 2004, pp. 327-330.
- [11] P. Gupta, A. B. Kahng, P. Sharma and D. Sylvester, "Gate-Length Biasing for Runtime-Leakage Control", *IEEE Trans. on Computer-Aided Design of Integrated Circuits and Systems*, 25(8), 2006, pp. 1475-1485.
- [12] V. Gutnik and A. Chandrakasan, "An Efficient Controller for Variable Supply-Voltage Low Power Processing", *IEEE Proc. Symposium on VLSI Circuits*, 1996, pp. 158-159.
- [13] R. Hegde and N. R. Shanbhag, "Energy-Efficient Signal Processing via Algorithmic Noise-Tolerance", *Proc. International Symposium on Low Power Electronics and Design*, 1999, pp. 30-35.
- [14] K. Jeong, A. B. Kahng and H. Yao, "Revisiting the Linear Programming Framework for Leakage Power vs. Performance Optimization", *Proc. of International Symposium on Quality Electronic Design*, 2009, pp. 127-134.
- [15] A. B. Kahng, S. Kang, R. Kumar and J. Sartori, "Designing a Processor From the Ground Up to Allow Voltage/Reliability Tradeoffs", to appear in *IEEE International Symposium on High-Performance Computer Architecture*, January 2010.
- [16] T. Kehl, "Hardware Self-Tuning and Circuit Performance Monitoring", *IEEE International Conference on Computer Design*, 1993, pp. 188-192.
- [17] P. Magnusson, M. Christensson, J. Eskilson, D. Forsgren, G. Hallberg, J. Hogberg, F. Larsson, A. Moestedt and B. Werner, "Simics: A Full System Simulation Platform", *Computer*, 35(2), 2002, pp. 50-58.
- [18] S. Narayanan, G. Lyle, R. Kumar and D. Jones, "Testing the Critical Operating Point (COP) Hypothesis using FPGA Emulation of Timing Errors in Over-Scaled Soft-Processors", *IEEE Workshop on Silicon Errors in Logic*, 2009.
- [19] J. Patel, "CMOS Process Variations: A Critical Operation Point Hypothesis", *Online Presentation*, 2008.
- [20] S. Sarangi, B. Greskamp, A. Tiwari and J. Torrellas, "EVAL: Utilizing Processors with Variation-Induced Timing Errors", *IEEE/ACM International Symposium on Microarchitecture*, 2008, pp. 423-434.
- [21] S. Sirichotiyakul, T. Edwards, C. Oh, R. Panda, and D. Blaauw, "Duet: An Accurate Leakage Estimation and Optimization Tool for Dual-Vt Circuits", *IEEE Trans. on Very Large Scale Integration (VLSI) Systems*, 10(2), 2002, pp. 79-90.
- [22] E. Chung and Jared Smolens, *OpenSPARC T1: Architectural Transplants*. <http://transplant.sunsource.net/>.
- [23] Intel Corporation, "Enhanced Intel Speed Step Technology for the Intel Pentium M Processor", *Microprocessors White Papers*, 2004.
- [24] *International Technology Roadmap for Semiconductors 2008 Update.*, <http://www.itrs.net/>.
- [25] *Sun OpenSPARC Project.*, <http://www.sun.com/processors/opensparc/>.
- [26] *Synopsys Design Compiler User's Manual.* <http://www.synopsys.com/>.
- [27] *Synopsys PrimeTime User's Manual.* <http://www.synopsys.com/>.
- [28] *Cadence SignalStorm User's Manual.* <http://www.cadence.com/>.
- [29] *Cadence SOCEncounter User's Manual.* <http://www.cadence.com/>.